

Short Field Take-off

Line up Checks:

- Compass / DG checked
- Brakes Applied
- Control column back
- Full throttle
- Static RPM 2280-2380
- Ts and Ps green
- Brakes Release

Rolling:

- Maintain Centreline
- Check ASI increasing

Lift-off at kt:

- Hold Best Angle Of Climb at kt

At 200ft:

- Lower nose to Best Rate Climb attitude
- passing 60kt, raise Flap
- After takeoff checks

